



Kimseed International Pty Ltd

ACN 108 508 336

4/5 Collingwood St

Tel: 61-8-94464377

Western Australia

ABN 37 108 508 336

Osborne Park 6017

Fax: 61-8-94463444

www.kimseed.com.au

Email: kimseed@kimseed.com.au

Kimseed Aspirator



The Kimseed High Volume Aspirator is designed to remove material from seeds and to do so quickly and efficiently. The Aspirator will separate seeds and impurities into 4 areas of the machine:

Heavies: Straight Down Medium: Centre Light: Right Side Very Light: Bag

Because of its precise flow adjustments separation can be extremely accurate.

Australian Native
Seed Specialists

Seed & Revegetation
Equipment

Engineering Design
& Fabrication

Forestry
Management

International Environmental
Consultants

Celebrating 37 years of sustainable land management


KS 2005

Preliminary Assembling:

The Aspirator may have been supplied partially assembled.

If this is the case follow these simple steps:

- 1) Replace bolts on Bag Supports
- 2) Place bag Support Rod
- 3) Re Install Both Bags. Bag with loop goes on top
- 4) Re-Install Castors placing locking castors at the front




OPERATION:

- 1) Once Aspirator is assembled, connect to power.
- 2) Set both seed adjustment ports to 1/3 opening.
- 1) Seeds to be cleaned should be dropped slowly from the top

ASPIRATOR



Fully Adjustable air suction vents allow total suction control regardless motor speed. This will allow suction control of all light material.



Heavies

mediums

lights